Murrelektronik Intelligent Current Operator

MURR

FIFKTRONIK

Installation instructions V1.7 MICO 2.4 Art.-No.: 9000-41042-0100400

MURR FIEKTRONIK

Technical data: Input va

Input values:		Signalling: See "Displays"	
Input voltage:		Environment:	
+24V DC (SELV/ PELV)		Storing temperature: -4	40°C to +80°C
Residual ripple of power supply		Environmental temperature: 0 to +55°C	
< 5% for one-phase, 2% for three-phase		Cooling by natural convect	ion
Range of working voltage		Safety:	
18-30 VDC		Rated insulation voltage: 5	0V
Frequency of power ON/OFF max 1 Hz		degree of pollution: 2	
Suppressor diode	36V	Classification of over-voltage	ge III
▲ No reverse polarity protection		Additional output protection:	
Total operating current:	8A (0 to +20%)	4A fuse for each channel ir	nternal
Maximum summation current of +24V		(UL 248-14, UL File E10480).	
terminals:	40A	Regulations:	
Output values:		EN 60529: Protective syst	em - IP20
Output current OUT1 & OUT2 adjustable to 1, 2, 3 or 4A		A EN 61000-6-2: Immunity to	o interference
The outputs meet the requirements for Class 2		EN 61000-6-3: Interference	emission class B
according to UL1310 / NEC Article 725		EN 60068-2-6: Oscillating	test
Nominal output voltage:		EN 60068-2-27: Shock tes	st
24V DC, corresponding	g to the input voltage		
Voltage drop at 4A per eac typical 160mV	h load branch:		
Turn ON capacity:			
max. 20mF* V		Weight: ca. 90g	
Internal fuse: 4 A delay fuse for each channel		Measurements LxWxD:	90x36x80 mm
* Dependent on: component tole	rance, conduit length, used power	supply, load current, selected current	range



Notice:

Please pay attention to the wire capability in relationship of its cross section, ambient temperature, current as well as the used protection. The in 4 levels settable channel current serves as the wire protection and device protection conform to EN60204-1, referring to the maximal permissible channel current. For lucid reasons this installation instructions does not contain detailed information to all types of this product and may not consider each fictitious case of erection, operation or installation. Continuing information may be taken from the data sheet or from our homepage in the internet

http://www.murrelektronik.com.

Schematic circuit diagram:

Technical alterations are reserved at any time. © 2005 Murrelektronik GmbH, Oppenweiler All rights reserved. Each reprint, even in parts, requires our written consent.

Murrelektronik GmbH P.O. Box 1165 Falkenstrasse 3 info@murrelektronik.com

D-71567 Oppenweiler Telefon +49(0)7191/47-0 D-71570 Oppenweiler Telefax +49(0)7191/47-130 http://www.murrelektronik.com

MICO 2.4 Art.-No. 9000-41042-0100400

Installation instructions



Functional description:

MICO 2.4 is a 2-channel electronic auxiliary circuit switch and serves as current monitoring. The operating voltage (+24V DC/at least 10A) is split into 2 current monitored load circuits (channels). When engaging the operating voltage the switched-on channels are time-delay activated (time-delay of each channel = 75 ms) to avoid overload current. The current selector switches (1) enable an independent setting of the operating currents of 1A, 2A, 3A or 4A (see disconnecting characteristic). When exceeding the operating current the corresponding channel will be disconnected pursuant to the disconnecting characteristic. In the event of voltage dip or power failure the current operating condition will be saved and reestablished after the recovery of the supply voltage. The setting of the current range during operation leads to the disconnection of the channel. It may only be switched on manually. Each channel may be manually connected or disconnected through the buttons (2). The current operating condition is signalised by the LED (2) - (red/green, see displays). All channels disconnected due to overload may be activated through ON (restart) (3) - see restart. In addition, the module is provided with a potential-free message output (4) to establish a summation message (see summation message). A bridging concept permits the lining-up on a 4-channel MICO module (maximum operating current 40A) without the installation of a cable system. For this purpose a bridging set is available as an option (see bridging set).

Bridging set: The bridging set minimises the efforts of wiring if multiple modules are joined together. It offers the possibility of bridging the following potentials:

+24V DC (7), GND (8), ON (6) and summary message (5). A connecting piece is necessary to anchor both modules (9). The bridging set is optionally available under:

> item no.: 9000-41034-0000001 (packing unit 10 pieces) item no.: 9000-41034-0000002 (packing unit 1 pieces)

MURR

FIEKTRONIK

Installation instructions V1.7 MICO 2.4 Art.-No.: 9000-41042-0100400

Safety instructions:

<u>Warning:</u> This equipment is only suitable for the operation on +24V DC (protection low voltage). The direct connection of this equipment may cause death, severe bodily injuries and considerable property damage.Only competent and qualified personnel may work on this equipment or in its proximity. The perfect and safe operation of this equipment requires the appropriate transportation, professional storage, erection and installation.

Attention:

- Only trained personnel shall open this equipment. Electrostatic sensitive device (ESD).
- During service work when manually disconnecting MICO, the operating company shall ensure that the system is protected against unintended reconnection (according to the currently applicable provisions BGV A3 (Trade Association Ordinance) or. EN 50110-1).
- Parallel switching of multiple load branches for increase of power is not permitted.
- Series connection of several MICO module to produce selective switch-off-characteristic is not allowed.
- A generated voltage at output is not allowed to be durably higher than the input voltage.

<u>Notice:</u> The GND connection of the equipment merely serves to supply the internal electronics. The O voltage of the consumer shall be conducted directly to the power supply through separate lines. The conductor cross-sections and line lengths must be adapted to the adjusted current range.

<u>Recommendation:</u> - Adjust the current range only if the channel is disconnected (red LED). - Lay GND wire as near and parallel as possible to the 24V line.

Installation: For the installation the pertinent DIN/VDE regulations or country-specific rules must be complied with. Assemble on support bar TH 35 pursuant to EN 60715. Due to operation-related heating the equipment must be assembled vertically so that the input terminals are on top. A free space of 30 mm above and below the equipment should be complied with. The connection of the supply voltage (24V DC) must be performed in accordance with VDE 100 and VDE 0160 and shall only be connected to a power supply with "safe separation" (SELV/PELV) corresponding to EN 60950-1 or 61558-2-6.

Condition at deliver	y: - Minimum current range of	Scope of delivery: - Module MICO 2.4
	each channel	 Installation instructions
	- Channel disconnected	- Designation labels
Accessories:	- Bridging set: (see bridging set)	/ - Designation labels: Art.No.: 996067

ON-Restart inputs: The Re-start – input is provided in double; it provides the user with the possibility of reconnecting load circuits disconnected by excess current by placing a defined signal at the input, e.g. 0V... 5V for "OFF" min. 1s long and 10V - 30V for "ON" min. 20ms long. This does not apply to manually disconnected channels. They may only be activated through the button (2) at the module.

Summation message: The summary output message is motivated by a potential-free message output (terminals 13 and 14); it opens as soon as a channel has been disconnected or short-circuit released by overload. The message output is capable of switching 30 VAC/DC at 100mA and is suitable to drive SPS inputs.



Pin connections and terminal assignment:

Terminals	Function	Terminal range	Remarks	
Input +24V	Connection Input voltage +24V	Max. 16 mm ² to AWG 6		
Input GND	Connection GND to supply the internal electronic	Max. 4 mm ² to AWG 12	<u>Notice</u> : The 0V of the consumer must lead directly to the voltage supply through separate lines!	
Output	MICO outputs to be connected	min.0,5 mm ²		
OUT 12	with the load circuit	to AWG20		
		max. 4 mm ²		
		to AWG 12		
ON	Remote activation (except	Max. 2.5 mm ²		
	function at manually	to AWG 12		
	disconnected channel [red])			
13, 14	Summation message contact	Max. 2.5 mm ²		
	(normally open contact)	to AWG 12		

Displays

Dispidys.				
Display	State	Indication		
green	connected	- Function OK		
red	disconnected	- Manually disconnected		
green flashing	threshold	- Load above 90% of operating current		
red flashing 1 Hz	disconnected	- Over current		
red quickly flashing 5 Hz	defect	- Internal fault		

Disconnecting characteristic:

Each current range is provided a separate disconnecting characteristic with a basic accuracy of 0...+20% – see diagram. The disconnecting time at short-circuit amounts to max. 5 m/s.

